

English

Works well on Windows 7 64 bit!
Compatible with Windows XP, 7 32/64 bit
NOT SUPPORT: MAC OS X, Linux

Instructions for installing the firmware:

1. Extract archive to folder (better on disk C:\ to folder C:\FW)
2. Open the folder C:\FW\RKBatchTool\Tools
3. Run application RKBatchTool_1.5.exe
4. Click button "..."
5. Select the firmware file (a file with **update.img** will be in the folder where the unzipped file for example: C:\FW\)
6. Get completely switch off iconBIT NetTAB SPACE II
7. Connect to the USB port of a PC or laptop (PC required port on the motherboard) USB => microUSB cable.
8. Press the "Vol -" and hold the USB cable to the microUSB port
9. Windows will search for the driver (if it is not previously installed). Select the driver folder RKBatchTool\Drivers (folder contains drivers for Windows 2000, XP, Vista, 7 32/64 bit)
10. If done correctly, the utility RKBatchTool_1.5.exe in the Connected Devices, the square of the number 1 will change from gray to green
11. Click "Upgrade" and wait for the firmware update procedure
Update consists of a few items at the end of the message window will show the selected characters *
If all goes well, you will see a message
***** Restore Done Success <1> Fail <0> Time <72322> ms *****

WARNING!

You may receive a validation error message after installing the firmware
If you see this message, it means that the firmware could not check after installation
But the device will work properly
You can try in this case, install the firmware again!

12. Now you can disconnect the USB cable from iconBIT NetTAB and enable it by pressing the Power button

Russian (Русский)

Хорошо работает на Windows 7 64 bit!
Совместимо с Windows XP, 7 32 /64 bit
Несовместимо с MAC OS X, Linux

Инструкция по установке прошивки:

1. Распаковать все в папку (лучше с на диске C:\ в папку C:\FW
2. Открыть в папку C:\FW\RKBatchTool\Tools
3. Запустить приложение RKBatchTool_1.5.exe
4. Нажать кнопку "..."
5. Выбрать файл прошивки (файл с именем update.img будет лежать в папке куда распаковали архив)
6. Взять полностью выключенный планшет (если включен, выполнить выключение)
7. Подключить к USB порту ПК или ноутбука (на ПК обязательно порт установленный на материнской плате) USB => microUSB кабель.
8. Нажать кнопку "Vol - " и не отпуская подключить кабель USB к порту планшета
9. Windows начнет поиск драйвера (если ранее драйвер не установлен). Выберете драйвер в папке RKBatchTool/Drivers (Папка содержит драйвера для Windows 2000, XP, Vista, 7 32 /64 bit)
10. Если все сделано верно, в утилите RKBatchTool_1.5.exe в поле Connected Devices, квадрат с номером 1 изменит цвет с серого на зеленый
11. Нажмите кнопку " Upgrade " и дождитесь окончания процедуры обновления прошивки
Обновление состоит из нескольких пунктов, по окончании в окне сообщений появится сообщение выделенное знаками *
Если все прошло хорошо, вы увидите сообщение
*****Restore Done Success<1> Fail<0> Time<72322>ms*****

ВНИМАНИЕ!

Возможно появление сообщений об ошибке проверки прошивки после установки
Если вы видите такое сообщение, это значит что прошивку не получилось проверить после установки
Но устройство будет работать нормально
Можно попробовать в таком случае установить прошивку еще раз!

12. Теперь можете отключить USB кабель от iconBIT NetTAB и включить его нажатием кнопку Power